



Seating options for EarthCruiser LWB.
When three or four is not a crowd.

For three.

Standard EarthCruiser leather suspension seat for driver. Factory FUSO seat rebuild to include lumbar support for both passengers. Center seat still folds down. Complete assembly can rise for engine services. Covered in matching leather.




Four four.

Hanging space is relocated to side of bed as shown in floor plan D (or can be deleted). Compliant travel seat can fitted beside dinette seat, when not in use makes a nice big comfy lounge.

Dinette in all EarthCruiser`s converts to a single bed. Bunk bed is available to go above dinette or above permanent double bed.

EarthCruiser EXP Long wheel base OPTION D.



1. HIGH=2510mm
 2. WIDE=2060mm
 3. LONG=6250mm
 4. *APPROX =45 degrees
 5. RAMP= 22 degrees
 6. DEPART=40 degrees
- Wheel track = 1752mm
Turning circle=13.6 MTR
Ground clearance=260mm

- A. DBL BED
- B. HANGING
- C. WC
- D. SHOWER
- E. SEAT (W BELT)
- F. DINETTE CHR
- G. SWING TABLE
- H. FRIDGE
- I. COOK TOP
- J. SINK

